
COMBO RACK




Assembly notes:


Fasteners provided to assemble machine: (100) 3/8"X3/4" Flange Bolts (4) 3/8"X4-1/2" Bolts (4) 3/8"X3-3/4" Bolts


Tools required (Not Included):


- 9/16" Open-End Wrench
- 9/16" Socket
- 4 ft ladder (recomended)


Note: When assembling unit DO NOT tighten any fasteners until specified.




















Instructions

14.) Assemble item 7 and 20 to items 6 using (2) 3/8"X4-1/2" bolts provided.

15.) Assemble items 7 to item 1 using (4) 3/8"X3/4" flange bolts provided.

16.) Assemble item 21 to item 6 using (2) 3/8"X3-3/4" bolts provided. (Note: 3 hooks face inside.)

17.) Tighten all bolts starting from the bottom to the top.

Hardware Detail

Item No.	Part Number	Part Name	Qty
8	99004	3/8"X3/4" FLANGE BOLT	4
22	99584	3/8''X4-1/2'' BOLT	2
23	99664	3/8''X3-3/4'' BOLT	2
24	99531	3/8" FLATWASHER	8
25	99540	3/8" NUT	2
26	99619	3/8" THIN NUT	2

