
# Plate Loaded Chest Press



#### **Assembly notes**:

Fasteners provided to assemble machine:

- (16) 1/2"X3-1/4" BOLTS
- (8) 1/2"X4" BOLTS
- (2) 3/8"X3-3/4" BOLTS
- (6) 3/8"X1-1/4" FLANGE BOLTS

#### Tools required (Not Included):

- 3/4" Open-End Wrench
- 3/4" Socket
- 9/16" Open-End Wrench
- 9/16" Socket
- 1/8" Allen Wrench

Note: When assembling unit DO NOT tighten any fasteners until specified.

### POWER LIFT ®

PART NUMBER


### 81274A\_assembly cover


THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF POWER LIFT ANY REPRODUCTION IN PART OR WHOLE WITHOUT THE WRITTEN PERMISSION OF POWER LIFT IS PROHIBITED


REV.

4

6/4/19







Instructions

- 5.) Assemble item 4 to item 5 using (2) 1/2"X4" bolts provided with thicker lock nuts.
- 6.) Then attach item 4 to item 3 using (2) 1/2"X4" bolts provided with thin lock nuts.
- 7.) Now tighten all bolts starting from the bottom working toward the top.

#### Hardware Detail

Item No.	Part Number	Part Name	Qty
14	99620	1/2"-13 NUT	2
16	80010	PLATE, SPACER	2
17	99521	1/2"X4"BOLT	4
18	99585	1/2" FLATWASHER	6
19	99571	1/2"-13, THIN NUT	2

# Frame Detail

 Item No. Part Number
 Part Name
 Qty

 3
 82310
 BRACE
 1

 4
 82311
 SEAT FRAME
 1


 5
 82312
 TOP BRACE
 1

PART NUMBER

81274A\_page3

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF POWER LIFT ANY REPRODUCTION IN PART OR WHOLE WITHOUT THE WRITTEN PERMISSION OF POWER LIFT IS PROHIBITED

REV. A Date 6/4/19



#### Instructions

- 8.) Make sure items 13 is on each end of item 8.
- 9.) Attach item 8 to item 7 using (4) 1/2"X3-1/2" bolts provided.

#### Hardware Detail


Item No.	Part Number	Part Name	Qty
14	99620	1/2"-13 NUT	4
15	99520	1/2"X3-1/2" BOLT	4
16	80010	PLATE, SPACER	4

## POWER LIFT ®

PART NUMBER 81274A\_page4

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF POWER LIFT ANY REPRODUCTION IN PART OR WHOLE WITHOUT THE WRITTEN PERMISSION OF POWER LIFT IS PROHIBITED

REV. Date 6/4/19



13

#### Instructions

- 10.) Make sure items 13 is on each end of item 2.
- 11.) Attach item 2 to item 1 using (4) 1/2"X3-1/2" bolts
- 12.) Tighten bolts on each arm while making sure both arms are aligned and move symmetrically.
- 13.) Check that set screws on bearings (Item #13) are tightened.

Item No.	Part Number	Part Name	Qty
14	99620	1/2"-13 NUT	4
15	99520	1/2"X3-1/2" BOLT	4
16	80010	PLATE, SPACER	4


POWER LIFT ®


PART NUMBER

81274A\_page5

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF POWER LIFT ANY REPRODUCTION IN PART OR WHOLE WITHOUT THE WRITTEN PERMISSION OF POWER LIFT IS PROHIBITED

Date 6/4/19





Instructions

15.) Attach item 9 to item 4 using the (4) 3/8"X1-1/4" bolts provided.

Note: DO NOT over tighten fasteners into Back Cushion.

### Hardware Detail

Item No.	Part Number	Part Name	Qty
60	99954	3/8"X1-1/4" BOLT	4

#### Frame Detail

Item No.	Part Number	Part Name	Qty
4	82311	SEAT FRAME	1
9	16587B	BACK CUSHION	1

## POWER LIFT ®

PART NUMBER 81274A\_page7

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF POWER LIFT ANY REPRODUCTION IN PART OR WHOLE WITHOUT THE WRITTEN PERMISSION OF POWER LIFT IS PROHIBITED

REV. Date 6/4/19